

#### **Specifications**

Product model: MLP-W

Dimension: 5.03\*5.03\*1.68inch

Weight: 0.95lb

Material: ABS .PC. Aluminum housing

Transmission distance: 10m

Bluetooth: V4.2

Speaker power: 3W\*2

Frequency Response: 150Hz-20KHz

Battery capacity: 2000mAh

Charging time: 3h

Input: 5V 1A

Playtime: 6h

#### **Packaging Content**

Little Player, User manual, USB cable, AUX audio cable, Warranty card

 $\bigstar$ With constant improvement of product, any adjustment of specifications or details will be adjusted without prior notice, so please make actual product as standard

\*Please read the user manual carefully before using product.

Congratulations to you

Your life space will be more colour ful and wonderful with BeeFo product.

# Start To Use Little Player...

Long press Power button for over 2S, LED ring will brighten and device is

When turning on, brightening symbol refers to battery level of Little Player.

When switching **Mode** to Bluetooth mode, BL will be displayed on Little Player. In mobile setting, open Bluetooth, search and connect to BeeFo Little Player. After successfully connecting, stylus light will

#### **Playing Function**

Move stylus to leftmost/rightmost to play/pause.
Touch any position on left/right half side of disc for twice to switch previous/next track.Rotate volume button to adjust volume





Move stylus

## **Time Display**

Switch Mode to clock mode and Little Player can be used as clock. Little Player only supports 24-hour system and touch any position on disc to display time for 8S. If there is any power connection, Little Player will display time continuously

When alarm is set, there will be two pages for time display. Slide towards left and right on disc for a short distance to view current time and alarm time



 $\star$  When playing music, short press **© Time** button to display time for 8S.

### **Set Time**

4

Under clock mode, long press Time button for time setting. Number of hour hand flickers slowly and it can be changed by sliding along disc. After target number is selected, remain the finger for a while, corresponding icon will brighten and flicker for three times, then the number is saved successfully. Repeat again to set number of minute hand until time setting is successful.

#### Turn on/off Clock

The position of switch also means on-off state of alarm.

#### Set Alarm Time

When alarm is enabled, it will enter setting of alarm time. Number of hour hand flickers slowly and it can be changed by sliding along disc. After target number is selected, long press any position on disc for over 1S, corresponding icon will brighten and flicker for three times, then the number is saved successfully. Repeat again to set number of minute hand until time setting







Long press for 1S Icon brightens Flicker for 3 times

★ Touching operation is influenced by static, environmental disturbance and contact area of finger. If any obstacle of saving through long pressing, it can be saved by short pressing **Time** button.

#### Start Snooze Mode


When the alarm rings, long press any position on disc for over 1S to start snooze mode. After 5 minutes, the alarm will ring again. Under snooze mode, alarm icon flickers slowly all the time. When the alarm is turned off, it will auit snooze mode.

 $\star$  Snooze mode can be repeated for three times at most and then the alarm will be turned off automatically

# Set Alarm Ringtone

Under clock mode, press (6) Time button successively for twice to enter ringtone setting.

Slide for a short distance along disc just like page turning and switch to select ringtone. When target ringtone is selected, long press any position on disc for over 1S, corresponding icon will brighten and flicker for three times, then ringtone setting is successful



Ringtone in Little Player Ringtone in TF card

There are 3 ringtones built in Little Player and audios in TF card also can be set as ringtone.

Please save audio files under /Ringstone catalogue of rootdirectory of TF card (build catalogue of same name). If the audio in TF card has been set as ringtone, please ensure that TF card is always remained in card slot of

#### **Reader Function**

Please insert TF card to the slot in interface area of Little Player and ensure that Little Player is under shutdown state. Connect USB cable to computer and Little Player will display USB mode.

Search USB DISK on computer to copy and read files.

\*Support FAT32/ExFAT/FAT64 file system, support 64G at most.

#### Set Delayed Shutdown

Under playing mode (including Bluetooth, TF card, AUX mode),long press **Time** button to enter setting of delayed shutdown. There are 4 pre-setting time on Little Player for selection. Slide for a short distance along disc to switch time. After selecting number, long press any position on disc for over 1S, corresponding icon will brighten and flicker for threetimes, then setting

After enabling delayed shutdown, Little Player will always display countdown. When time terminates, stop playing current music and switch to clock mode



Long press Time button again to cancel function of delayed shutdown.

### Adjust Brightness

Short press **OPower** button to adjust brightness of digital screen and it's divided into high/middle/low grade. Note: the brightness of LED ring can't be adjusted.

# **AUX IN Mode**

Switch **Mode** to AUX mode and ensure related audio playing device has

**TF Card Mode** 

5

Switch function to TF card mode and ensure that TF card with audio files has been inserted.

Press both up and down ends on disc for over 1S at the same time to enter

Slide along disc and switch number of songs

Touch any position on left/right half side of disc for twice to switch front/next



# Bluetooth Call

When Bluetooth of Little Player is under connection state, call options will appear if any incoming call. Long press any position on left/right half side of disc to hang up/answer call.

